

F MODEL INSTRUCTIONS

(Supplement to Owner's Manual)

This sheet contains the necessary revisions to the Owner's Manual for the "F" model shock.

SECTION I INSTALLATION

2. Pressure Hose Hole Location.

Yamaha YZ 250F/400F: The pressure hose should exit the shock cavity on the left side just in front of the tank. Locate the hole in the circular section approximately 2½ inches forward of the front shock mount pin. Follow the drilling procedure outlined on Page 8.

SECTION II PRESSURIZING

Recommended Pressures

Table 2. Fox Mono Airshock Pressure Recommendations (psi) for Yamaha YZ F Models.

SHOCK PRESSURE (psi)	RIDER WEIGHT (lbs)										
	120	130	140	150	160	170	180	190	200	210	220
250 F	173	179	186	192	199	205	212	218	226	231	238
400 F	179	186	192	199	205	212	218	226	231	238	244

SECTION IV MAINTENANCE

Oil Refill Quantities

11" F Model Fox Mono Airshock (2 spacers)	434cc
12" F Model Fox Mono Airshock (1 spacer)	438cc
13" F Model Fox Mono Airshock (no spacer)	442cc

(over)